


Handed

ML19 Side Jamb Pivot


3/4" Offset

Installation Instructions


Door should already be hung with top pivot and bottom pivot (or floor closer)


1.  Mortise door & frame per template on reverse side.


2.  Affix pivot to door & frame.


3.  Align pivot point from top pivot to bottom arm. (See diagram)


4.  Loosen arm screw*.


5.  Remove hex cap.

6.  Turn stud screw clockwise. Raise the door to the desired height.

7.  Using shims furnished with bottom arm, fill gap between arm and base.



8.  Turn stud screw counterclockwise until door rests on shims.

9.  Tighten arm screw on spindle. Open and close door several times. Re-tighten arm screw.

10.  Replace hex cap.

**Side Jamb Pivot
for Heavy or Leadlined Door
3/4" Offset – Handed**



Rixson Specialty Door Controls


www.rixson.com

NUMBER

IS-ML19

DATE

8-06



Door Thickness	A	B	Max. Lead Thickness
1-3/4 (44.4)	1-1/4 (31.8)	1/4 (6.4)	9/32 (7.1)
2 (50.8)	1-1/2 (38.1)	5/16 (7.9)	3/8 (9.5)
2-1/4 (57.1)	1-3/4 (44.4)	5/16 (7.9)	15/32 (11.9)
2-1/2 (63.5)	2 (50.8)	5/16 (7.9)	9/16 (14.3)
3 (76.2)	2-7/16 (62)	5/16 (7.9)	3/4 (19)

For Door Thickness Not Listed—Use Next Size Smaller for Prep

Notes:

1. Do not scale drawing.
2. Dimensions are given in inches (mm).
3. Pivot drilled for 1/4-20 x 3/4" FHMS or #14 x 1-1/2" FHWS.
4. Right hand shown.

**Side Jamb Pivot
for Heavy or Leadlined Door
3/4" Offset – Handed**



Rixson Specialty Door Controls

www.rixson.com

NUMBER

IS-ML19

DATE

8-06